




FITTING INSTRUCTIONS FOR L.H.D ROD **LINKAGE MODELS**

Follow the fitting instructions as for R.H.D models but at instruction 11 it will be found that the steering box occupies the Bulk Head Support as shown in fig. 4B (see fitting instructions)

The removed bracket (instruction 10) will need modifying and re-fitting in order to connect the linkage assembly to the carb.



Reid Trading Estate, Factory Road, Sandycroft,
Deeside, Flintshire U.K. CH5 2QJ.

Tel: 01244 539196

Fax: 01244 539529

E-mail: sales@acr-demon.co.uk